



Owner's Manual

Safety Instructions Customer Service Operation

Safety Instructions

WARNING: This equipment is for home use only. Do not use in institutional or

commercial applications. Failure to follow this warning could result in death

or serious injury.

WARNING: This product contains a chemical known to the State of California to cause

cancer and birth defects or other reproductive harm.

WARNING: To reduce the risk of serious injury, read the following Safety Instructions

before using the AB Session.

- Save these instructions and ensure that other exercisers read this manual prior to using the AB Session for the first time.
- The AB Session should only be used after a thorough review of the Owner's Manual. Make sure that it is properly assembled and tightened before use.
- Keep children away from the AB Session. Do not allow children to use or play on the AB Session. Keep children and pets away from the AB Session when it is in use.
- 4. It is recommended that you place this exercise equipment on an equipment mat.
- Set up and operate the AB Session on a solid level surface. Do not position the AB Session on loose rugs or uneven surfaces.
- 6. Make sure that adequate space is available for access to and around the AB Session.
- Before using, inspect the AB Session for worn or loose components, and securely tighten or replace any worn or loose components prior to use.
- 8. Consult a physician prior to commencing an exercise program and follow his/her recommendations in developing your fitness program. If at any time during exercise you feel faint, dizzy, or experience pain, stop and consult your physician.
- Always choose the workout which best fits your physical strength and flexibility level. Know your limits and train within them. Always use common sense when exercising.
- 10. Do not wear loose or dangling clothing while using the AB Session.
- 11. Never exercise in bare feet or socks; always wear proper footwear such as running, walking, or cross training shoes that fit well, provide foot support, and feature non-skid rubber soles.
- 12. Be careful to maintain your balance while using, or assembling the AB Session, loss of balance may result in a fall and serious bodily injury.
- 13. The **AB Session** should be used by only one person at a time.
- 14. The **AB Session** is for consumer use only. It is not for use in public or semipublic facilities.

This Product is Produced Exclusively by



2040 N. Alliance, Springfield, MO 65803
Customer Service
1 (800) 375-7520
customerservice@staminaproducts.com
www.staminaproducts.com

When calling for parts or service, please specify the following model number: 05-0874

MADE IN TAIWAN
© 2015 Stamina Products, Inc.
2015, 07

Assembly Instructions


NOTE: Do not tighten any bolts until STEP 4.

STEP 1

Refer to the letter indicators (A) on the parts. Insert the HANDRAILS(6) into the CONNECTING BAR A(5) and secure with BUTTON HEAD BOLTS(M6x1x30mm)(11), LOCK WASHERS(M6)(9), and ACORN NUTS(M6x1)(10).

STEP 2

Position the HOUSINGS(1) to make the logo facing out. Insert the HANDRAILS(6) into the HOUSINGS(1) and secure with BUTTON HEAD BOLTS(M6x1x40mm)(12), LOCK WASHERS(M6)(9), and ACORN NUTS(M6x1)(10).




Assembly Instructions

STEP 3


Refer to the letter indicators (B) on the parts. Slide the HEADREST FOAM PAD(7) onto the CONNECTING BAR B(4). Insert the UPPER HEADREST SUPPORTS(3) into the CONNECTING BAR B(4) and secure with BUTTON HEAD BOLTS(M6x1x30mm)(11), LOCK WASHERS(M6)(9), and ACORN NUTS(M6x1)(10).

STEP 4

Refer to the letter indicators (C) on the parts. Insert the HEADREST SUPPORTS(2) into the UPPER HEADREST SUPPORTS(3) and secure with BUTTON HEAD BOLTS(M6x1x30mm)(11), LOCK WASHERS(M6)(9), and ACORN NUTS(M6x1)(10). Insert the HEADREST SUPPORTS(2) into the HOUSINGS(1) and secure with BUTTON HEAD BOLTS(M6x1x40mm)(12), LOCK WASHERS(M6)(9), and ACORN NUTS(M6x1)(10). Tighten all bolts from STEP 1 to STEP 4.



Product Parts Drawing and Parts List



Part	No. and Description	Qty	Par	t No. and Description	Qty
1	Housing	2	9	Lock Washer (M6)	20
2	Headrest Support	2	10	Acorn Nut (M6 x 1)	20
3	Upper Headrest Support	2	11	Bolt, Button Head (M6 x 1 x 30mm)	12
4	Connecting Bar B	1	12	Bolt, Button Head (M6 x 1 x 40mm)	8
5	Connecting Bar A	1	13	Wrench	1
6	Handrail	2	14	Allen Wrench (4mm)	1
7	Headrest Foam Pad	1	15	Owner's Manual	1
8	Foam Grip	2			